




Quick Reference

Instrument - Overview



Buttons - Overview




Device ON/OFF	
Short push	Power ON
Long push (>5s)	Power OFF

Operation	
Short push	Scroll right, select, adjust
Long push (>1.4s)	Start new series (Store current series and start new series) Operation possible at any time



Operation	
Short push	Scroll down
Long push (>1.4s)	Backlight on/off
Long push (>5s)	Power OFF

Main Screen - Overview



Main Menu - Overview

Mode

Configuration of operation mode

LIVE using the app
PRINT using a BT printer

Standard

Select standard

ASTM → Rebound value according to ASTM D5873
ISRM → Rebound value according to International Societ of Rock Mechanics
WG → Weathering Grade according to ISRM
MEAN
MEDIAN

Memory

Clear memory

Info

Show device information

Menu - Navigation



HOME/MEASUREMENT screen



MAIN MENU



Mode Selection



SCROLL



SELECT



Standard selection



SCROLL



SELECT/ADJUST



Clear Memory



SCROLL



SELECT




Unsyncronized data will be lost



HOME/MEASUREMENT screen



Measurements




Auto-switch off

No activity > 5 minutes →

- Current series is saved
- Current series is closed
- Power off

Viewing Results

Scroll through results



Return to series



Delete whole series

Start new series

	S0075
	NEW
<input type="text"/>	





SCROLL




SELECT/ADJUST

Printing Results


Scroll through results



Return to series



Print series	S0075		SCROLL
Delete whole series	S0075		SELECT/ADJUST
Start new series	+ NEW		



Further Information


Requires a BT printer → available as accessory

Configuration for printing → [Mode selection](#)

SWISS  MADE

For more information on the product use of the product,
please refer to the Rock Schmidt RS8000 documentation

It is available for download on



[www.screeningeagle.com/en/
products/rock-schmidt-rs8000](https://www.screeningeagle.com/en/products/rock-schmidt-rs8000)

ASIA-PACIFIC

Proceq Asia Pte Ltd.
1 Fusionopolis Way
Connexis South Tower #20-02
Singapore 138632
T +65 63823966

CHINA

Proceq Trading Shanghai Co., Limited
Room 701, 7th Floor, Golden Block
407-1 Yishan Road, Xuhui District
200032 Shanghai | China
T +86 21 6317 7479

EUROPE

Proceq AG
Ringstrasse 2
8603 Schwerzenbach
Zurich | Switzerland
T +41 43 355 38 00

UK

Screening Eagle UK Limited
Bedford i-lab, Stannard Way
Priory Business Park
MK44 3RZ Bedford
London | United Kingdom
T +44 12 3483 4645

MIDDLE EAST AND AFRICA

Proceq Middle East and Africa
Sharjah Airport International
Free Zone | P.O.Box: 8365
United Arab Emirates
T +971 6 5578505

USA, CANADA & CENTRAL AMERICA

Screening Eagle USA Inc.
14205 N Mopac Expressway Suite 533
Austin, TX 78728 | United States

Screening Eagle USA Inc.
117 Corporation Drive
Aliquippa, PA 15001 | United States
T +1 724 512 0330

SOUTH AMERICA

Proceq SAO Equipamentos
de Medição Ltda.
Rua Paes Leme 136
Pinheiros, Sao Paulo
SP 05424-010 | Brasil
T +55 11 3083 3889